tcontrol

toscano

TPUMP-W

Ed. 2.23



ENGLISH (EN) User manual WiFi communication device with IoT connectivity for TPM7 and VIGILEC COMPACT series devices

CONTENIDO



Installation must be performed by an electrician.



It is essential to read this technical manual before proceeding.

SAFETY WARNINGS

ATTENTION! Before making any adjustments, it is essential to connect the motor or pump to the equipment to avoid unexpected tripping of the underload protection (minimum load 0.5A). We recommend that you follow all locally approved safety instructions and procedures when working with electrically connected equipment. Important safety information is listed below. For the safe installation and operation of this equipment, make sure to read and understand all cautions and warnings. A WARNING: Before installing, operating, doing maintenance, or testing this equipment, please read and understand the contents of this manual. Improper operation, handling, or maintenance could cause death, serious personal injury and damage to the equipment. A WARNING: This equipment is not designed to safeguard human lives. Follow all locally approved safety procedures and practices when installing or operating this equipment. Failure to do so could cause death, serious personal injury and damage to the equipment. A WARNING: Dangerous voltages. Contact with electrical current will cause serious personal injury or death. Follow all locally approved safety procedures when working around high voltage lines and equipment. A WARNING: This equipment requires regular inspection and maintenance to ensure proper operation. If it is not maintained properly, it could stop working correctly. Improper operation could cause equipment damage and possibly result in personal injury. A WARNING: All connections must be made by a qualified person. There is a risk of electric shock if this precaution is not followed. A WARNING: Additional pump motor protection can be added when required during installation. A WARNING: If the equipment is used or modified outside of what is specified by the manufacturer, Toscano disclaims all responsibility for improper use. The interior of the equipment should only be handled by our technical service personnel.

1. GENERAL DESCRIPTION

TPUMP-W is designed to provide IoT connectivity via WiFi to compatible devices through an app. It offers real-time monitoring, alarms and timers for an optimal user experience.



2. INSTALLATION



To connect to compatible equipment, use the RJ connector at the top.

3. USAGE

3.1. INSTALLING AND STARTING THE APP



1 Download the "Tpump-W" App



Registro de usuario

Email Email

Pw Repetir contraseña Pw Enviando este formulario acepta nuestra política de gestión de datos





First screen without associated devices.



4 Tap on "+" and follow the instructions.



:	Mis dispositivos	Añadir dispositivo
		 Alta del dispositivo Vuelve a la APP, Añadr dispositivo
	No hay dispositivos emparejados a este usuario	Tpump_ XXXXXXX
	Emparejar	Enviar
		3. Posibles errores a) En caso de que el led Wifi esté encendido fijo, es posible que ya esté conectado a una red wifi, para cambiar la red, apague y encienda el dispositivo con el botón pulsado hasta que el led empiece a parapadear (Reset Fábrica).
	Dispositivos Alarmas Más	b) En caso de que no aparezca la pantalla -Configure WIF-1 d. Asegúress que está conectado a Tpool_xoxxxxx vaya al navegador de su dispositivo e introduzca esta dirección 192.168.4.1.

ENGLISH (EN)

3.2. DEVICE PAIRING

To use TPUMP-W, the device must be installed and connected to a WiFi network. The WiFi LED flashes continuously.

Wi-Fi

Lise Wi-Fi

TOSCANO_I+D+i

Tpump-W_56666549

TOSCANO SR 2 4GHz

TOSCANO W 2.4GHz

Preferencias de Wi-Fi

MiFibra-D5A1

- 1 Go to the "Networks and Internet" section on your smartphone, a network called "Tpump-W_xxxxxxx" should appear, copy the number xxxxxxx and connect to this network.
- 2 A screen will appear in your browser, if it does not appear, see the "Miscellaneous" section. Click on "Configure WiFi".
- 3 Next, a menu will open that will allow you to select the WiFi network to which you want to connect TPUMP-W, enter the password and click on "Save".
- 4 After a few seconds, if everything is correct, the WiFi LED will stop flashing and will become fixed, otherwise it is possible that the password is not correct and you will have to repeat the process.



If everything is correct, we must return to the APP to complete the registration of our device. Enter the number and click on "Send". If everything is correct, you will be returned to the main screen, click on \bigcirc to display the device. If it does not appear, it may be because the RJ11 connector is not connected or the equipment to be controlled is switched off.

If the RJ11 is connected, the corresponding device will appear on the screen.

The functions of the App will depend on the equipment to which it is connected.



4. OPERATION

🗩 WiFi status LED

Power status LED Indicates if the device is switched on

Flashing: not connected / Steady: connected

Solo para equipos con esta función.

Indicates the WiFi status.

Timer status LED



Used to reset/factory reset TPUMP-W and reset the timer



5. ALARM

There are alarms in TPUMP-W related to WiFi/Internet.

Not connected to the Router



If the LED flashes continuously there is no WiFi connection, in this case it may be due to:

- First connection
- Factory reset
- Router switched off or faulty. Lack of coverage.

In this case, if we access via WiFi, it will take us to connect to a new WiFi network.

Connected to Router but no internet access

The LED flashes cyclically.

6. RESET

Factory Reset

This reset will remove the device from the database and erase the connection to the router. Press and hold the **FUNC** button with the **TPUMP-W** turned off. Switch the device on and off, the WiFi LED will blink until it connects to the WiFi network and the LED will turn to solid. It is important that it connects to the Internet, after a few seconds the LED will turn off, it will flash again and you will be able to stop pressing the button.

7. MISCELLANEOUS

- In the first installation and in case you are connected to the TPUMP-W via WiFi and the APP to pair does not appear, go to your browser and enter the **IP 192.164.4.1**
- On first installation, if the application interface does not appear, check that the WiFi LED is on and the RJ11 cable is correctly connected.

8. APP OPERATION

The operations in the app will depend on the device to which it is connected. There are general functions that are the same for several models and others that are specific to the device model.

8.1. DESCRIPTION OF GENERIC FUNCTIONS

- When you start the App (logged in) or when you click on "Devices" you access the screen where all your devices are located.
- By clicking on "Alarms", we go to the alarm screen of all the devices you have installed.
- By clicking on "More", we go to the generic functions of the "APP".



8.2. DESCRIPTION OF SPECIFIC AND COMMON FUNCTIONS PER MODEL

There are common functions among the different device models, such as:

- Alarms.
- Share device.
- Real-time information.

There are specific functions depending on which equipment TPUMP-W is connected to.

9. COMPATIBLE EQUIPMENT

9.1. V1B



Screen displaying equipment parameters

Sensor 4-20 A

9.2. V2B



Datalogger

(
C	< Vigilec	
	BOMBA 1	
	lmax B1	7.0 A
	Horas de marcha	42
	Nº arranques	21
	Nº saltos térmicos	5
	I.última alarma	8.9 A
	Reset de contadores	0
	BOMBA 2	

Setup screen



Screen displaying equipment parameters

9.3. V2MB



9.4. V1M / V1N



Setup screen

<	Vigilec		Device name
	T-Connect Usuarios asociados	•	Change device name
i	Manuales	•	View
i	ID: 56676556	•	manual Serial number

Datalogger

< Vigilec	
Horas de marcha	67
Nº arranques	293
Nº saltos térmicos	242
l.última alarma	5.8 A
Reset de contadores	2

Screen time

							_	
P	RUG	KAIVI	ACIO	NI				
	8	8		8	8	8	START	15:0
ī.	м	x	J	v	s	D	STOP:	15:0
Ρ	ROG	RAM	ACIÓ	N 2				
0				0			START	12:3
	Ō	Õ	Ō	U	Ō	ō	STOP:	12:4
P	ROG	RAM	ACIÓ	N 3	0			
							START	08:0
0	8	8	8	8	8	8	CTOD-	0.0-0
L	Μ	Х	J	V	S	D	0101.	00.0
P	ROG	RAM	ACIÓ	N 3			(
A	A	A		A			START	22:5
U L	М	×	J	v	s	D	STOP:	23:5

It has four independent timers to program the use of the equipment, click on the parameter to change it.

ck on "SAVE SETTINGS" to save the changes.
--

9.5. TPM7



Setup screen

	Tpump-W		Device name
	T-Connect Usuarios asociados		Change device name
i	Manuales	•	View
i	ID: 56676556	•	manual Serial number

Datalogger

< Tpump-W	
· · · · · · · · · · · · ·	
Horas de marcha	67
Nº arranques	293
Nº saltos térmicos	242
l.última alarma	5.8 A
Reset de contadores	2

9.6. TPM7/5



Datalogger

	\sum
< трм7/5	
Horas de marcha	0
Nº arranques	27
Nº saltos térmicos	23
l.última alarma	0%
Reset de contadores	0

10. COMMON SCREENS

10.1. ALARM SCREENS

In this screen we have the specific alarms of the equipment, where we will find information about the incidents of the equipment.

(($ \rightarrow $
	< 🖸 Vigilec	
	Search 12:38-14/06/21	
-	T-Connect	GENE 0.0 A
\mathcal{L}		

10.2. ASSOCIATED USERS SCREEN



11. TECHNICAL CHARACTERISTICS

Power supply	100/240 VAC 50/60Hz
power consumption	250 mA máx.
Measures (mm)	90 x 65 x 18 mm (Length x Width x Depth)
Weight	150 g
Antena	External, 2 metres of cable
Wi-Fi	2,4 GHz band 802.11b/g/n

Distribuido por Adajusa

toscano Línea Electrónica, S.L. Av. A-92, Km. 6,5 - 41500 - Alcalá de Guadaíra - SEVILLA - SPAIN (+34) 954 999 900 - www.toscano.es - info@toscano.es